


PARTS DIAGRAM R5 VERSION 2402



PARTS DIAGRAM R5 VERSION 2402

No.	Name	Qty
1	Wheel axle cap	2
2	Split pin	2
3	Wheel	2
4	Washer 20	4
5	Wheel axle	1
6	Belt cover	1
7	Bolts M6*16/washer 6/ spring washer 6	3
8	Rotor key	1
9	Pulley rotor	1
10	V-belt	1
11	Bolts M8*20/washer 8/ spring washer 8	5
12	Rotor housing cover	1
13	Belt cover holder back	1
14	Bolts M8*25/ nut M8/washer 8/ spring washer 8	8
15	Inner hexhead bolts M10*20/washer 10/ spring washer 10	2
16	Bolts M8*25/big washer 8/ spring washer 8	2
17	Anvil	1
18	Bearing assy.	2
19	Bolts M10*25/washer 10/ spring washer 10	8
20	Bearing cover	1
21	Hinge pin	1
22	Engine plate	1
23	Tension plate	1
24	Nut M8/washer 8/ spring washer 8	8
25	Engine	1
26	Engine shaft bush	1

28	Engine key	1
29	Lock washer	2
30	Bolts M8*25/ spring washer 8	2
31	Bolts M8*40/ thin nut M8/washer 8	2
32	Rotor housing	1
33	Blade bolts	4
34	Blade	2
35	Rotor	1
36	Belt cover holder front	1
37	Bolts M6*12/washer6/ spring washer 6	3
38	Rubber bumper	1
39	Nut M10/washer 10	1
40	Front support	1
41	Bolts M8*16/ washer 8/ spring washer 8	8
42	Output	1
43	Washer 6	1
44	Knob M6*16	1
45	Deflector	1
46	Bolts M6*16/washer6/ locknut M6	2
47	Hopper	1
48	Bolts M6*16/washer6/ locknut M6	4
49	Hopper tray	1
50	Flap strip	1
51	Flap	1
52	Bolts M6*20/washer6/ locknut M6	3

PARTS DIAGRAM R5 VERSION 2402

27	Pulley engine	1
----	---------------	---