



ASSEMBLY DRAWING LIST



QR PROFI three-point linkage

Ser.No	Code	Name & Specification	Quantity
1	140001	Connection adjuster link	1
2	N000033	Lock nut M16	3
3	W000017	Washer M16	6
4	B000246	Bolt M16×70	2
5	140005	Fixate pin	1
6	400034	Lock pin 4.5	3
7	140007	Connecting rod	1
8	000082	Grease Nipples M8	1
9	N000039	Lock nut M8	2
10	W000021	Washer M8	4
11	B000069	Bolt M8×65	2
12	N000030	Lock nut M10	2
13	W000014	Washer M10	4
14	B100001	Bolt M10×60	2
15	140015	Trailer hook EU	1
16	140016	Trailer hitch connecting link	1
17	B000047	Bolt M16×85 (10.9 Level)	1
18	140018	Connecting body	1
19	W000028	Washer M18	2
20	140020	Connecting body shaft	1

ASSEMBLY DRAWING LIST



QR PROFI series

Ser.No	Code	Name & Specification	Quantity
1	140024	Wheel cover	2
2	B000083	Bolt M12×25	3
3	W000002	Spring washer M12	3
4	W000010	Big washer 12	3
5	140028	Bearing 6205-2RZ	4
6	W000011	Big washer 14	2
7	N000032	Lock nut M14	2
8	W000014	Washer M10	26
9	W000001	Spring washer M10	15
10	B000077	Bolt M10×35	8
11	140034	Wheel holder plate (Right) 1	1
12	B000234	Bolt M10×20	12
13	140036	Wheel adjustment axis	2
14	W100002	Lock washer M22	2
15	N000129	Lock nut M22	2
16	140039	Height adjustment ring	2
17	B000109	Bolt M8×16	4

QR PROFI series

Ser.No	Code	Name & Specification	Quantity
18	W000008	Spring washer M8	8
19	W000013	Big washer 8	2
20	K000011	Key 6×20	2
21	140125	Quick release screw	2
22	B000111	Bolt M8×25	2
23	100023	Roller connect plate (Right)	1
24	000094	Grease Nipples M6	4
25	140048	Wheel adjustment axle block (Right)	1
26	140049	Adjustment ruler	2
27	B001132	Bolt M5×10	12
28	140051	Adjustment ruler marker	2
29	140052	Wheel holder plate (Right) 2	1
30	140053	Self-lubricating bearing 18x20x20	4
31	140054	Wheel adjustment axis tube	2
32	N000031	Lock nut M12	42
33	W000015	Washer M12	28
34	140057	Wheel support (Right)	1
35	140058	Wheel holder plate bushing	2
36	140059	Wheel support bushing	2
37	300019	Self-lubricating bearing 30×34×25	2
38	B000138	Bolt M8×25	10
39	W000021	Washer M8	8
40	N000039	Lock nut M8	4
41	140064	Scraper for 120	1
42	100028	Bearings UC205	2
43	B000085	Bolt M12×35	12
44	140067	Back roller for 120	1
45	140068	Wheel holder plate (Left) 2	1
46	100040	Roller connect plate (Left)	1
47	140070	Wheel adjustment axle block (Left)	1
48	140071	Wheel holder plate (Left) 1	1
49	140072	Wheel sleeve	2
50	140073	Wheel support (Left)	1
51	140074	Engine el-start	1
52	140075	Pulley cover	1
53	140076	Main body for 120	1
54	B000221	Bolt M10x45	4
55	N000030	Lock nut M10	6
56	140079	Wheels 16×6.5-8×3.75	2
57	140080	Corner oil cup M6×90	3
58	000082	Grease Nipples M8	2
59	400111	Adjust plate (Left)	1
60	140083	Left wheel protection	1
61	100073	Combination bolt M12×30	8
62	100074	Bearings UC207	2
63	140086	Screw knob M8×90	2

QR PROFI series

Ser.No	Code	Name & Specification	Quantity
64	000092	Hammer	28
65	B000030	Bolt M12×75 (10.9 Level)	28
66	140089	Battery cover	1
67	140090	Battery holder	1
68	B000074	Bolt M10×20	4
69	140092	Battery	1
70	P000005	Cotter pin 4×25	2
71	N000033	Lock nut M16	2
72	120104	Small baffle	10
73	120105	Big baffle	6
74	140097	Baffle shaft for 120	1
75	140098	Main roller for 120	1
76	OS000005	Oil seal 55×80×10	1
77	140100	Sleeve	1
78	400094	Adjust plate (Right)	1
79	600063	T cover	1
80	B000110	Bolt M8×20	4
81	700058	Self-lubricating bearing 25×28×30	2
82	140105	Tensioning device	1
83	700055	Round tip set	1
84	B000075	Bolt M10×25	4
85	700064	Tensioning spring	1
86	S000017	Circlip for hole 40	1
87	140110	Right wheel protection	1
88	S000006	Circlip for hole 62	1
89	140113	Bearing 6206-2RZ	2
90	S000018	Circlip for hole 30	1
91	140114	Tension wheel	1
92	000055	Rubber	1
93	140116	Belt guard shield	1
94	140117	Plate for belt protection	1
95	B000148	Rivet Ø4×8	4
96	100049	Tension 35×60	1
97	140120	Small pulley	1
98	140121	Belt 17×1036	3
99	140122	Bolt 24×35	1
100	140123	Clutch sleeve	1
101	140124	Clutch with pulley	1